

ACB 400

ACB 400	A	B	Hz	V	Fase Phase
010656	168991	500633	50	400	1~
010657	168992	500639	60	380	3~

